

Sticky Mat

Accessories



Cleaning by being sticky

Adhesive-coated contamination control mats or sticky mats are formulated and developed to meet the stringent cleanroom particulate specifications. Used on entryways, walkways, traffic areas where particle contamination is to be controlled. It is composed of easy to peel-off, disposable sticky mat layers that can effectively capture 99% all foot-borne and wheel-borne particulates from entering the controlled working environment. Each mat is composed of multiple layers of polyethylene films coated with custom high tack adhesive laminated together into a stack.

908.101.0030	Sticky Mat 1 45 x 115 cm	Unit: 30 peel-able sheets
908.101.0040	Sticky Mat 1 45 x 115 cm	Unit: 40 peel-able sheets
908.102.0030	Sticky Mat 2 65 x 115 cm	Unit: 30 peel-able sheets
908.103.0030	Sticky Mat 3 92 x 153 cm	Unit: 30 peel-able sheets

Characteristics:

- ◆ Easy to peel to the next sheet by tags on one of the corners
- ◆ Water-based acrylic adhesive with PH in between 7-8
- ◆ Doesn't contain benzoic acid, 45 micron --> high stickiness
- ◆ Certified RoHS, free from heavy metals and hazardous chemicals.
- ◆ Shelf-Life: 5 years after production date

